

Model PRESET 8 Installation and Operations Manual



Doug Fleenor Design, Inc.
396 Corbett Canyon Road
Arroyo Grande, CA 93420
(805) 481-9599 Voice and FAX

Product description

The Preset 8 is a lighting control station that stores eight preset looks. Each look, or scene, has an associated slider that adjusts the light levels for that look. The preset looks are recorded into the Preset 8 by capturing the output of any DMX512 console.

Preset 8 systems may consist of single or multiple stations. Systems with multiple stations utilize a Main/Remote concept in that the looks are recorded into the Main stations with the remote stations controlling some, or all, of the levels.

Environmental

Operating temperature: 0-40° C (32-104° F)
Operating humidity: 10-90% non-condensing
Indoor use only


Electrical ratings

Input: 12-24 volts AC or DC, 100 mA maximum
A common “doorbell” transformer can be used as a power source. The Doug Fleenor Design model XFMR can be used to power up to four Preset 8 stations.

System layout

Cabling used for DMX512 signals to and from the Preset 8 stations must be specified for DMX512 usage. Examples include Belden 9829 and Belden 9729 or their equal.

Low voltage power cabling for the Preset 8 may be run in the same conduit with the DMX512 cabling. Doug Fleenor Design suggests using #16 AWG wire for station power cabling.



General notes:

Preset 8 stations must be connected to one another on the input or “upstream” side of DMX splitters or processing devices. All DMX cabling must be installed in a “daisy chain” or “touch-and-go” wiring fashion. DMX cabling using “star”, “T”, or “Y” configurations will result in unreliable operation.

Station power cabling may be wired using any topology that is convenient. However, it is usually most convenient to run the low voltage power cabling along with the DMX cabling.

Doug Fleenor Design recommends against using the “spare” pair of wire in many DMX cables to carry power to the Preset 8 stations. The wire gauge is inadequate to prevent excessive voltage drop. Unreliable operation may result from this practice.

Main station wiring:

The DMX signal from a control console must be connected to the three pin DMX IN terminal block (TB2).

The DMX output signal from the Preset 8 is available on the five pin terminal block (TB1). The common, data plus, and data minus signals

Input power to the station should also be connected to this terminal block. The POWER COMMON and 12-24V AC/DC terminals are used for power input to the Preset 8 stations. Take care to observe proper polarity when connecting DC power to the Preset 8. A low voltage AC source can be used to power the Preset 8. The low voltage AC power must be within the range of 12 – 24V. Note that if a single transformer is used to power multiple stations, all stations must be wired with the same polarity. It does not matter which wire from the transformer is connected to the C terminal, but the same wire must be connected at all stations. Failure to observe proper polarity may result in a damaged transformer which will not be covered by any warranty.

IMPORTANT NOTE: DO NOT APPLY 120VAC POWER TO THE PRESET 8. THE STATION WILL BE DAMAGED BEYOND REPAIR AND WILL NOT BE COVERED BY ANY WARRANTY.

Remote station wiring:

All DMX cabling to and from a Preset 8 Remote station must be connected to the five pin terminal block (TB1). The cable from the prior station and the cable going out to the next station (or other DMX devices) will be connected to the same terminals on the five pin terminal block (TB1). The three pin terminal block (TB2) is not used by Remote stations. **No cables are to be connected to the three pin terminal block (TB2) if the station is configured as a Remote station.**

Remote stations may be connected to the Main station input or output connectors. The Main station supports Remote stations on both its input and output ports simultaneously. However, only a total of four Remote stations are supported. Each Remote station must have its own unique ID (described later in this document) regardless of which Main station port it is connected to.

Input power to the station must be connected to the five pin terminal block. The POWER COMMON and 12-24V AC/DC terminals are used for power input to the Preset 8 stations. Take care to observe proper polarity when connecting DC power to the Preset 8. A low voltage AC source can be used to power the Preset 8. The low voltage AC power must be within the range of 12 – 24V. Note that if a single transformer is used to power multiple stations, all stations must be wired with the same polarity. It does not matter which wire from the transformer is connected to the C terminal, but the same wire must be connected at all stations. Failure to observe proper polarity may result in a damaged transformer which will not be covered by any warranty.

IMPORTANT NOTE: DO NOT APPLY 120VAC POWER TO THE PRESET 8. THE STATION WILL BE DAMAGED BEYOND REPAIR AND WILL NOT BE COVERED BY ANY WARRANTY.

Jumper settings


There are six jumpers on the rear of the Preset 8. All are installed at the factory. This configures the Preset 8 as a Main station which will support most applications. To enable additional features, jumpers can be removed as shown by the table below.

Jumper	Function when installed	Function when removed
1	Record lockout disabled	Record lockout enabled
2	Main station	Remote station
3	Hold last DMX input disabled	Hold last DMX input enabled
4	Single station mode	Multi-station mode (remote station support)
5	Station controls locked while DMX present	DMX piles onto station levels
6	Not assigned	Not assigned

Mounting

The Preset 8 can be mounted in most 3-gang electrical boxes. Raco model 692 box is included with each station. Other boxes may be used provided they have a depth of at least 2 inches.

The Preset 8 must be mounted with the hidden record switch/signal indicator hole to the right. If the Preset 8 is mounted upside down, the sliders will work in reverse. Observe the "UP" marking on the rear of the Preset 8 for additional verification.



Configuring Remote stations

There must be one (and only one) Main station. The Main station can support up to four Remote stations. If there is only one Remote station, no configuration other than proper jumper setting is required. However, if there are two or more Remote stations, they must be configured to insure reliable communications with the Main station. This following process is used to set each Remote station's unit ID.

Setting a Remote station's unit ID:

- Configure the jumpers on the Preset 8 for Remote station operation (remove JP2 and JP4).
- Set all sliders to their lowest position.
- Apply power to the station.
- Using a paper clip or similar object, press and HOLD the record button. Note: the red record LED will not illuminate at any time during this process.
- Raise the slider which corresponds to the new unit ID you wish to assign. For example, if you wish to set the station's unit ID to 2, raise slider 2 to full while holding the record button. Note that only sliders 1 – 4 can be used. Raising sliders 5 – 8 will have no effect.
- Lower the slider to zero.
- Release the record button.

This process must be repeated for each Remote station assigning each one a unique unit ID. Up to four Remote stations can be supported. The unit IDs do not need to be in order of the connected stations and unused unit IDs are allowed. For example, a system may consist of a Main station and two Remote stations with unit IDs of 1 and 3.

The Remote station configuration process only needs to be performed once. Each station's unit ID is held in non-volatile memory and is recalled upon power-up.

Recording a preset

The Preset 8 comes from the factory with DMX slot 1 recorded at full on slider 1. DMX slot 2 is recorded at full on slider 2, etc.

The Preset 8 takes a "snapshot" of the final DMX512 data output. The snapshot can be composed of levels from the incoming DMX512 signal, from other sliders, or from a combination of the two.

RECORDING CAN ONLY BE PERFORMED ON THE MAIN STATION. Preset recording can not be done from a Remote station.

To record a preset onto a slider, perform the following steps.

- Using a DMX512 source or other already-recorded presets, create a new look to be recorded.
- At the Main station, use a paper clip or similar object to momentarily press and release the recessed record button between sliders 7 and 8. The red record LED will start to flash slowly.
- Move the slider to be recorded to its lowest position (if it isn't there already).
- Move the slider to be recorded to full. The red record LED will stop flashing. This indicates that the Preset 8 has successfully recorded the final output levels into the selected slider's memory. If a DMX512 input signal is present, the LED will turn on solid. If no DMX512 is present, the LED will turn off.
- Repeat this process for each slider's preset as needed.

Setting levels using the sliders

If jumper 5 is installed (pile on mode is disabled), the Main station's sliders will only be active while no DMX512 input is present. The red signal LED will be off if there is no DMX512 input. If the Main station is configured for pile on, the incoming DMX512 levels will be added to the levels from the Preset 8's recorded scenes. Simply move the sliders on the station to the desired levels.

Using Remote stations

When multiple Preset 8 stations are installed, one is designated as the Main station and all others are Remote stations. However, from the user's perspective, any station can gain control of a slider at any time. This is done through a "match and grab" mechanism. A user might raise slider 1 to full to turn

on the lighting look recorded in that scene. When the user arrives at another station, slider 1 might be in the lowest position. If the user wishes to vary the level of the scene at this new station, he must raise the number 1 slider to full (matching its current level on the first station). Once the slider level matches that of the first station, the new station's number 1 slider can be used to change the level of the slider 1 scene. This action can be repeated at any station at any time. Each slider is separately "grabbed" thus allowing different sliders on different stations to be in control at the same time.

Troubleshooting

Problem description: Flashing, flickering, lack of control

Solution 1:

Verify that the DMX cabling has been terminated properly. Often, the data plus and data minus wires are swapped. Reverse the data plus and data minus wires and/or verify them at each station. Nearly every trouble call we receive is due to installation wiring errors. Please check before calling.

Solution 2:

A DMX compliance problem on the part of the DMX receiving devices often leads to these symptoms. The Preset 8 uses short manufacturer-specific command packets to communicate between Main and Remote stations. Devices claiming DMX512 compliance should ignore these packets. However, some fixtures do not properly ignore the manufacturer-specific packets resulting in flashing or flickering.

In such situations, the manufacturer of the non-compliant should address the problem. If they are unable or unwilling to do so, Doug Fleenor Design offers the DMX DECELERATOR. This device can be connected in the DMX line just before the non-compliant devices. It will remove the manufacturer-specific packets and only pass generic DMX data packets.

Solution 3:

Lack of proper end-of-line termination. DMX cabling must be terminated at the end of the run with a 120 ohm terminating resistor between the data plus and data minus signal.

Problem description: Main station operates, but Remote stations will not work

Solution 1:

The Main station and/or the Remote station are connected to the output of a splitter or other DMX processing device. Preset 8 stations must only be connected to the input of a splitter or other DMX processing device. Main and Remote stations must also be directly connected to one another with no active devices between them. Insure that the Main station and any Remote stations are wired to the input of a splitter.

Solution 2:

Remote station has been wired using the three pin terminal block (TB2). All wiring on Remote stations must be made on the five pin terminal block ONLY. See the section on Remote station wiring.

Problem description: Setting levels on Remote stations causes the lights to jump rather than doing a match-and-grab as described in the manual.

Solution:

This indicates that there are two or more Remote stations set to the same ID. Each Remote station must have a unique ID. Read the section on configuring remote stations.

Limited Manufacturer's Warranty

Products manufactured by Doug Fleenor Design (DFD) carry a five-year parts and labor warranty against manufacturing defects. It is the customer's responsibility to return the product to DFD at the customer's expense. If covered under warranty, DFD will repair the unit and pay for return ground shipping. If a trip is necessary to the customer's site to solve a problem, the expenses of the trip must be paid by the customer.

This warranty covers manufacturing defects. It does not cover damage due to abuse, misuse, negligence, accident, alteration, or repair by other than by Doug Fleenor Design.

Most non-warranty repairs are made for a fixed \$50.00 fee, plus shipping.

Doug Fleenor Design, Inc.

396 Corbett Canyon Road
Arroyo Grande, CA 93420
(805) 481-9599 voice and FAX
(888) 4-DMX512 toll free (888) 436-9512
web site: <http://www.dfd.com>
e-mail: info@dfd.com

