

## GALAXY AUDIO PA6S BOOM MOUNT KIT INSTRUCTIONS

### Contents:

3/8-16 x 2" Carriage Bolt

Lock Washer

Large Black Locking Knob

Locking Thumbnut

Rubber Washer

### Assembly:

Components should be assembled on the bolt as shown below.



### Hardware Installation:

1. Slide the assembly fully into the slot at the top of the PA6S cabinet (the handle area), with the head of the bolt underneath the slot and the lock washer on top of the cabinet as shown below.
2. Tighten the large black locking knob as much as possible by hand.



### Boom Installation:

1. Screw on the boom of your choice allowing at least 1/2" of thread engagement on the bolt. Some booms may require a 5/8"-27 to 3/8"-16 thread adapter. If so, make sure the adapter is fully tightened in the boom assembly. The boom assembly will contact the flat rubber washer, which sits on top of the locking thumbnut.
2. Tighten the locking thumbnut just enough to maintain the desired boom position. The combination of the thumbnut and rubber washer will allow some side-to-side swiveling of the boom without causing the large locking knob to loosen.
3. The fully assembled boom mount is shown below. For transport, the boom may be removed from the PA6S by simply loosening the large locking knob. The mounting hardware will stay with the boom.

