





Blizzard Lighting, LLC www.blizzardlighting.com Waukesha, WI USA Copyright (c) 2016

TABLE OF CONTENTS

То	urnado™ EXA	1
1.	Getting Started	3
	What's In The Box? Getting It Out Of The Box Powering Up! Getting A Hold Of Us Safety Instructions (Don't run with scissors!)	3 3 3 3 4
2.	Meet The Tournado™ EXA LED Par	5
	Main Features DMX Quick Reference The Tournado™ EXA Pin-up Picture	5 5 6
з.	Setup	7
	Connecting A Bunch Of Tournado™ EXA Fixtures Data/DMX Cables Setting the DMX Input Connector as the Active DMX Input Cable Connectors 3-Pin??? 5-Pin??? Huh? Take It To The Next Level: Setting up DMX Control Fixture Linking (Master/Slave Mode) Mounting/Rigging	7 7 8 8 9 9
4.	Operating Adjustments	10
	Navigating The Control Panel Control Panel Menu Structure DMX Mode Set the Starting DMX Address Setting the DMX Channel Mode Slave Mode Dimming Mode Settings LED Display On/Off Custom Programs Auto Mode, and Auto Speed Color Calibration Settings Custom Static Colors & Preset Colors Fixture Reset Functions Data Sync Feature Fixture Information DMX Value In-Depth Reference Guide DMX In-Depth Reference	10 11 12 12 12 12 12 13 13 13 14 14 14 15 15 15 16 17
5.	Appendix	18
	A Quick DMX Lesson Troubleshooting Keeping Your Tournado™ EXA As Good As New Returns (Gasp!) Shipping Issues Tech Specs Dimensional Drawings	18 18 19 19 19 20 21

1. GETTING STARTED

What's In The Box?

- 1 x Tournado[™] EXA Professional LED PAR Fixture
- 1 x IP Rated AC power cord
- 1 x Set of IP Rated DMX in/out cables
- This Lovely User Manual

Getting It Out Of The Box

Congratulations! You're now the proud owner of one tough, slightly pumpkin shaped PAR fixture! And now that you've got your TOURnado™ (or hopefully, TOURnados!), you should carefully unpack the box and check the contents to ensure that all parts are present and in good condition. If anything looks as if it has been damaged in transit, notify the shipper immediately and keep the packing material for inspection. Again, please save the carton and all packing materials. If a fixture must be returned to the factory, it is important that the fixture be returned in the original factory box and packing.

Powering Up!

All fixtures must be powered directly off a switched circuit and **cannot be run off a rheostat (variable resistor) or dimmer circuit, even if the rheostat or dimmer channel is used solely for a 0% to 100% switch**.

AC Voltage Switch - Not all fixtures have a voltage select switch, so please verify that the fixture you receive is suitable for your local power supply. See the label on the fixture or refer to the fixture's specifications chart for more information. A fixture's listed current rating is its average current draw under normal conditions. Check the fixture or device carefully to make sure that if a voltage selection switch exists that it is set to the correct line voltage you will use.

Warning! Verify that the voltage select switch on your unit matches the line voltage applied. Damage to your fixture may result if the line voltage applied does not match the voltage indicated on the voltage selector switch. All fixtures must be connected to circuits with a suitable Ground (Earthing).

Getting A Hold Of Us

If something happens goes wrong, please visit www.blizzardlighting.com/ support and open a support ticket. We'll be happy to help, honest.

Disclaimer: The information and specifications contained in this document are subject to change without notice. Blizzard Lighting[™] assumes no responsibility or liability for any errors or omissions that may appear in this user manual. Blizzard Lighting[™] reserves the right to update the existing document or to create a new document to correct any errors or omissions at any time. You can download the latest version of this document from www. blizzardlighting.com.

Author:	Date:	Last Edited:	Date:	
J. Thomas	5/29/2014	J. Thomas	9/22/2016	

SAFETY INSTRUCTIONS

Please read these instructions carefully. They include important information about the installation, usage and maintenance of this product.

• Please keep this User Guide for future use. If you sell the unit to someone else, be sure that they also receive this User Guide.

• ALWAYS make sure that you are connecting to the proper voltage, and that the line voltage you are connecting to is not higher than that stated on the decal or rear panel of the fixture.

• Make sure there are no flammable materials close to the unit while operating.

• The unit must be installed in a location with adequate ventilation, at least 20in (50cm) from adjacent surfaces.

• ALWAYS disconnect from the power source before servicing or replacing fuse and be sure to replace with same fuse size and type.

• ALWAYS secure fixture using a safety chain. NEVER carry the fixture by its cord. Use its carrying handles.

• DO NOT operate at ambient temperatures higher than 104°F (40°C).

• In the event of a serious operating problem, stop using the unit immediately. NEVER try to repair the unit by yourself. Repairs carried out by unskilled people can lead to damage or malfunction. Please contact the nearest authorized technical assistance center. Always use the same type spare parts.

- NEVER connect the device to a dimmer pack.
- Make sure the power cord is never crimped or damaged.
- Never disconnect the power cord by pulling or tugging on the cord.
- Avoid direct eye exposure to the light source while it is on.

Caution! There are no user serviceable parts inside the unit. Do not open the housing or attempt any repairs yourself. In the unlikely event your unit may require service, please open a support ticket at www. blizzardlighting.com/support.

2. MEET THE TOURNADO™ EXA LED PAR

CONTROL FEATURES

- RGBAW+UV color mixing via 12x 15W 6-in-1 LEDs
- LED control panel with 4 touch sensitive electronic buttons
- Super-sharp 25° beam angle
- Variable electronic dimming & strobe
- Built-in color & chase macros via DMX
- Built-in automated programs via master/slave
- RGBAW+UV color mixing ability in standalone mode
- User selectable 4/5/6/7/9 or 12-channel DMX modes

ADDITIONAL FEATURES

- Rugged and well-built (It hits the gym regularly)
- Convection cooled cast aluminum housing
- Dual mounting brackets for positioning flexibility
- Flicker-free constant-current LED driver
- IP rated locking power and 3-pin DMX connections

Channel	12-Channel	9-Channel	7-Channel
1	Dimmer	Dimmer	Dimmer
2	Red Intensity	Red Intensity	Red Intensity
3	Green Intensity	Green Intensity	Green Intensity
4	Blue Intensity	Blue Intensity	Blue Intensity
5	Amber Intensity	Amber Intensity	Amber Intensity
6	White Intensity	White Intensity	White Intensity
7	UV Intensity	UV Intensity	UV Intensity
8	Strobe	Strobe	
9	Custom Colors + Auto	32-bit Dimming	
10	Auto Speed		
11	Virtual Color Wheel		
12	32-bit Dimming		

DMX Quick Reference - 12/9/7-Channel Modes


DMX Quick Reference - 6/5/4-Channel Modes

Channel	6-Channel	5-Channel	4-Channel
1	Red Intensity	Dimmer	Red Intensity
2	Green Intensity	Amber Intensity	Green Intensity
3	Blue Intensity	White Intensity	Blue Intensity
4	Amber Intensity	UV Intensity	White Intensity
5	White Intensity	Virtual Color Wheel	
6	UV Intensity		

Figure 1: The Tournado[™] EXA Pin-Up Picture



Figure 2: The Rear Connections



3. SETUP



Before replacing a fuse, disconnect power cord. ALWAYS replace with the same type and rating of fuse.

Fuse Replacement

CAUTION! The Tournado[™] EXA utilizes a high-output switch-mode power supply with an internal fuse. Under normal operating conditions, the fuse should not require replacement. The fuse is field replaceable, however it is an advanced procedure suited to qualified individuals. Should your Tournado[™] EXA fuse require replacement, please contact Blizzard Lighting for instructions, or to return your unit for service.

Connecting A Bunch of Tournado[™] EXA Fixtures

You will need a serial data link to run light shows using a DMX-512 controller or to run shows on two or more fixtures set to sync in master/slave operating mode. The combined number of channels required by all the fixtures on a serial data link determines the number of fixtures the data link can support.

Fixtures on a serial data link must be daisy chained in one single line. Also, connecting more than 32 fixtures on one serial data link without the use of a DMX optically-isolated splitter may result in deterioration of the digital DMX signal.

The maximum recommended cable-run distance is 500 meters (1640 ft). The maximum recommended number of fixtures on a serial data link is 32 fixtures.

Data/DMX Cabling


To link fixtures together you'll need data cables. You should use datagrade cables that can carry a high quality signal and are less prone to electromagnetic interference.

For instance, Belden© 9841 meets the specifications for EIA RS-485 applications. Standard microphone cables will "probably" be OK, but note that they cannot transmit DMX data as reliably over long distances. In any event, the cable should have the following characteristics:

2-conductor twisted pair plus a shield Maximum capacitance between conductors – 30 pF/ft. Maximum capacitance between conductor & shield – 55 pF/ft. Maximum resistance of 20 ohms / 1000 ft. Nominal impedance 100 – 140 ohms

Cable Connectors

Cables must have a male XLR connector on one end and a female XLR connector on the other end. (Duh!)



A Word on Termination: DMX is a resilient communication protocol, however errors still occasionally occur. Termination reduces signal errors, and therefore best practices include use of a terminator in all circumstances. If you are experiencing problems with erratic fixture behavior, especially over long signal cable runs, a terminator may help improve performance.

To build your own DMX Terminator: Obtain a 120-ohm, 1/4-watt resistor, and wire it between pins 2 & 3 of the last fixture. They are also readily available from specialty retailers.



CAUTION: Do not allow contact between the common and the fixture's chassis ground. Grounding the common can cause a ground loop, and your fixture may perform erratically. Test cables with an ohm meter to verify correct polarity and to make sure the pins are not grounded or shorted to the shield or each other.

3-Pin??? 5-Pin??? Huh?!?

If you use a controller with a 5-pin DMX output connector, it's no problem! you can simply use the installed 5-pin DMX input and/or output connections found on the back of your fixture(s).


Conductor	3-Pin Female (Output)	5-Pin Male (Input)
Ground/Shield	Pin 1	Pin 1
Data 1- (Primary Data Link)	Pin 2	Pin 2
Data 1+ (Primary Data Link)	Pin 3	Pin 3
Data 2- (Optional Secondary Data Link)	Pin 4	Pin 4
Data 2+ (Optional Secondary Data Link)	Pin 5	Pin 5

Take It To The Next Level: Setting Up DMX Control

Step 1: Connect the male connector of the DMX cable to the female connector (output) on the controller.

Step 2: Connect the female connector of the DMX cable to the first fixture's male connector (input). *Note:* It doesn't matter which fixture address is the first one connected. We recommend connecting the fixtures in terms of their proximity to the controller, rather than connecting the lowest fixture number first, and so on.


Step 3: Connect other fixtures in the chain from output to input as above. Place a DMX terminator on the output of the final fixture to ensure best communication.



Fixture Linking (Master/Slave Mode)

1. Connect the (male) 3-pin connector side of the DMX cable to the output (female) 3-pin connector of the first fixture.

2. Connect the end of the cable coming from the first fixture which will have a (female) 3-pin connector to the input connector of the next fixture consisting of a (male) 3-pin connector. Then, proceed to connect from the output as stated above to the input of the following fixture and so on.



A quick note: Often, the setup for Master-Slave and Standalone operation requires that the first fixture in the chain be initialized for this purpose via either settings in the control panel or DIP-switches. Secondarily, the fixtures that follow may also require a slave setting.

Check the "**Operating Adjustments**" section in this manual for complete instructions for this type of setup and configuration.

Mounting & Rigging

This fixture may be mounted in any SAFE position provided there is enough room for ventilation.

It is important never to obstruct the fan or vents pathway. Mount the fixture using a suitable "C" or "O" type clamp. The clamp should be rated to hold at least 10x the fixture's weight to ensure structural stability. Do not mount to surfaces with unknown strength, and ensure properly "rated" rigging is used when mounting fixtures overhead.

Adjust the angle of the fixture by loosening both knobs and tilting the fixture. After finding the desired position, retighten both knobs.

• When selecting installation location, take into consideration lamp replacement access (if applicable) and routine maintenance.

- Safety cables MUST ALWAYS be used.
- Never mount in places where the fixture will be exposed to rain, high humidity, extreme temperature changes or restricted ventilation.

4. OPERATING ADJUSTMENTS

The Control Panel

All the goodies and different modes possible with the Tournado[™] EXA are accessed by using the control panel on the rear of the fixture. There are 4 control buttons below the LED display which allow you to navigate through the various control panel menus.

<MENU>

Is used to navigate to the previous higher-level menu item.

<UP>


Scrolls through menu items and numbers in ascending order.

<DOWN>

Scrolls through menu items and numbers in descending order.

<ENTER>

Is used to select and confirm/store the current selection.



The control panel LED display shows the menu items you select from the menu map on page #11. When a menu function is selected, the display will show immediately the first available option for the selected menu function. To select a menu item, press **<ENTER>**.

Use the **<UP>** and **<DOWN>** buttons to navigate the menu options. Press the **<ENTER>** button to select the menu function currently displayed, or to enable a menu option. To return to the previous option or menu without changing the value, press the **<MENU>** button.

Control Panel Menu Structure

ADDR	001-512		To choose the DMX address			
STAT	R			y (0% <> 100%)		
	G		Green intens	sity (0% <> 100%)		
	В			y (0% <> 100%)		
	A			sity (0% <> 100%)		
	W			sity (0% <> 100%)		
	UV			UV intensity (0% <> 100%)		
	SHUT PRSC (preset colors)		Flash / strobe speed (0-255)			
			NONE, R, G,	B, A, W, UV, YELLOW, PINK, CYAN, ORANGE, VIOLET, 00K, 3200K, 4000K, 5500K, 6500K, RGBW		
SET	CAL		To set globa	l intensity levels of each color + USE: YES/NO		
	CHMD	12CH	To run in 12	-channel mode		
		9CH	To run in 9-o	channel mode		
		7CH	To run in 7-o	To run in 7-channel mode		
		6CH	To run in 6-o	channel mode		
		5CH	To run in 5-o	channel mode		
		4CH	To run in 4-o	channel mode		
	DIM	LIN	Linear dimm	ing curve		
	(dimming)	SQR	Square law of	curve		
		ISQR	Inverse squa	are law curve		
		SCUR	S-curve			
		LIN.	Linear dimming curve (smooth)			
		SQR.	Square law curve (smooth)			
		ISQR.	Inverse square law curve (smooth)			
		SCUR.	S-curve (smooth)			
	DISY	ON	LED menu display is on continually			
	2MIN		LED menu display shuts off after 2 minutes of inactivity			
	LOCK	YES/NO	To unlock, press the buttons in this order: <menu>, <up>, <down>, <enter>, <menu>, <up>, <down>, <enter>, <menu>, <up>, <down>, <enter> with no longer than 3 sec- onds between each button press.</enter></down></up></menu></enter></down></up></menu></enter></down></up></menu>			
CTST	CT01-CT10	<enter></enter>	R/G/B/W ad	justments for custom color banks 01-10		
AUTO	AT01-AT05	<enter></enter>	Auto programs 1-5			
	ATSP	<enter></enter>	Auto Speed			
	CHS1	<enter></enter>	Custom prog	gram 1		
	CHS2	<enter></enter>	Custom prog	gram 2		
	CHS3	<enter></enter>	Custom prog	gram 3		
PROG	CHS1-CHS3	SC01-SC20	R (0-255)	SHUT (strobe, 0-255)		
	Custom programs	20 scenes	G (0-255)	AUTO (None, AT01-AT05)		
	1-3.	for each custom	B (0-255)	ATSP (speed, 0-255)		
		program.	A (0-255)	TIME (duration, 0-255)		
			W (0-255)	WAIT (before fade, 0-255)		
			UV (0-255)	USE (use scene, YES/NO)		
INFO	SOFT	Vx.x	Software ver	rsion information		
		POW		omated overheat protection level (100%/80%/50%)		
	STL		Restore factory settings			
LOAD	STL		restore race			
LOAD	ST L PR L			ory program settings		

DMX Mode

Allows the unit to be controlled by any universal DMX controller.

Setting the DMX Address:

The default mode for the fixture is DMX, which appears as **001** on the LED readout. To select a different DMX address, using the **<MENU>** button, select **ADDR**, then hit **<ENTER>**. Use the **<UP/DOWN>** buttons to select the correct address, then hit **<ENTER>** to confirm.

Setting the DMX Channel Mode:


 To select a DMX channel mode, press the <MENU> button, then use the <UP/DOWN> buttons until the display reads SET and press the <ENTER> button. Then use the <UP/ DOWN> buttons until the display reaches CHMD, and press <ENTER>. Now press the <UP/ DOWN> buttons again to highlight your desired DMX channel mode, and press the <ENTER> button to confirm.

Slave Mode:

Daisy chain the fixtures DMX in/out, having the controller at the beginning of the line.
There is nothing else to it! The first fixture in the DMX chain is the master fixture, and the following fixtures will follow the master.

Dimming Mode Settings:

Allows users to set the fixture to use 1 of 4 (x2) dimming curve settings for smoother (and slower) dimming capabilities. In the control panel menu, there are two settings for each curve that are distinguishable from one another by the trailing dot.



*The curve settings with the trailing dot adds a bit more delay to the curve for a smoother effect.

 Use the <MENU> and <UP/DOWN> buttons to navigate to SET and press <ENTER>, then <UP/DOWN> buttons again to scroll to DIM, and press the <ENTER> button.
Now use the <UP/DOWN> buttons to highlight either LIN (Linear), SQR (Square), ISQR (Inverse Square), SCUR (S-Curve), LIN. (Smooth Linear), SQR. (Smooth Square), ISQR. (Smooth Inverse Square), or SCUR. (Smooth S-Curve), then hit <ENTER>.

LED Display On/Off:

1.) Use the **<MENU>** and **<UP/DOWN>** buttons to navigate to **SET** and press **<ENTER>**, then navigate to **DISY**, and press the **<ENTER>** button.

2.) In **DISY**, you can set the LED menu display to be continually on, or shut off after 2 minutes of inactivity.

Custom Programs:

Allows users to create up to 3 customizable, 20 scene programs that are directly accessible via the control panel and also in DMX mode.

Creating A Custom Program:

Use the <MENU> and <UP/DOWN> buttons to navigate to PROG, and press <ENTER>.
Now use the <UP/DOWN> buttons to highlight your choice of either CHS1, CHS2, or CHS3 and press <ENTER>.

3.) Start with editing scene 1 (SC01), customizing it to your liking by using the choices outlined in the table below. You can insert any of its 5 built-in auto programs (AT01-AT05), and adjust its speed (ATSP 0-255), and also set the duration (in seconds) before moving on to the next scene (TIME 0-255). You can also add a fade in effect to the start of this scene (WAIT 0-255), and/or strobe (SHUT 0-255). Finally, if you want to use this scene in your program, *be sure to enable it* (USE: YES/NO).

4.) Repeat the above process to create up to 20 scenes in each of the 3 customizable programs.

R (0-255) - Red Intensity	UV (0-255) - UV Intensity	WAIT (0-255) - Fade In (fast - slow)
G (0-255) - Green Intensity	SHUT (0-255) - Strobe (slow - fast)	USE (YES/NO) Use Scene in Program?
B (0-255) - Blue Intensity	AUTO (AT01-AT05) - Auto Programs	IMPORTANT:
A (0-255) - Amber Intensity	ATSP (0-255) - Auto Speed (fast - slow)	If USE is set to NO, or TIME is set
W (0-255) - White Intensity	TIME (0-255) - Scene Time (seconds)	to 0, the scene will not run!

Running A Custom Program:

1.) To view your newly created lighting masterpiece, use the **<MENU>** and **<UP/DOWN>** buttons to navigate to **AUTO**, and press **<ENTER>**.

2.) Use the **<UP/DOWN>** buttons to highlight your choice of either **CHS1, CHS2,** or **CHS3** and press **<ENTER>**. These are also directly accessible from the **Effect Channel** in DMX mode.

Auto, Modes, and Auto Speed:

Set single or Master/Slaved units to run auto modes at user selectable speeds.

Auto Mode:

1.) Use the **<MENU>** and **<UP/DOWN>** buttons to navigate to **AUTO**, and press the **<ENTER>** button.

 Now use the **<UP/DOWN>** buttons to highlight any program ranging from **AT01-AT05**, and press **<ENTER>**.

Auto Speed:

Use the <MENU> and <UP/DOWN> buttons to navigate to AUTO and press <ENTER>, then with the <UP/DOWN> buttons navigate to ATSP, and press the <ENTER> button.
Make a selection from 0-255, and press <ENTER> to choose a speed (slow <--> fast).

Color Calibration Settings:

Allows the user to setup and save 1 customized R/G/B/A/W/UV color balance setting and save it for future use. This custom setting is global, and it will effect all modes.

1.) Use the **<MENU>** and **<UP/DOWN>** buttons to navigate to **SET** and press **<ENTER>**, then on while **CAL**, push **<ENTER>** again.

2.) Use the **<UP/DOWN>** buttons to highlight either **R** (Red Level), **G** (Green Level), **B** (Blue Level), **A** (Amber Level), **W** (White Level), or **UV** (UV Level), then hit **<ENTER>**.

3.) Now using the **<UP/DOWN>** buttons, select the maximum level for each color between 000-255 (000=off), and hit **<ENTER>** to confirm your choice.

4.) You have now just setup and saved a custom global color calibration setting that you can use at you convenience. To use your custom setting now (or later), press the **<UP/DOWN>** buttons to reach **USE**, and press **<ENTER>**. Then choose either **YES** or **NO** and press **<ENTER>**. When you select **YES**, it enables this custom color calibration globally, and when choosing **NO** the fixture will continue to use the default color calibration settings. Your customized settings will be saved for later use even after powering off the fixture. It can be altered to your liking at any time. Just remember to return to this setting to either enable or disable it when needed.

Custom Static Colors & Preset Colors:

Allows the user to create and save custom static colors for use in standalone or DMX mode.

Static Color Mixing and Preset Mixed Colors

Important: When finished editing and saving a static color, you must return to (and stay on) any one of the editing screens (0-255) to make the effect stay on continually. If you were only to press **<ENTER>** to save your final edit, you would again be on the static color/effect selection menu, which from here will result in blackout mode after 1 minute.

Use the <MENU> and <UP/DOWN> buttons to navigate to STAT and press <ENTER>, then <UP/DOWN> buttons to select R/G/B/A/W/UV, and push <ENTER> to confirm your selection. Then in adjust the values (0-255) to your liking and press <ENTER> to save.
In the same manner, you can select SHUT to add s strobe effect.

3.) You can also select **<PRSC>** and use the **<UP/DOWN>** buttons to scroll through and quickly use any of the fixtures built-in preset colors.

Mix and Save Custom Colors (1-10)

1.) Use the **<MENU>** and **<UP/DOWN>** buttons to navigate to **CTST** and press **<ENTER>**, then **<UP/DOWN>** buttons to select a color bank from **CT01-CT10**, and push **<ENTER>** to confirm your selection.

2.) Now use the **<UP/DOWN>** buttons to highlight either **R** (Red Level), **G** (Green Level), **B** (Blue Level), **A** (Amber Level), **W** (White Level), or **UV** (UV Level), then hit **<ENTER>**.

3.) Finally, using the **<UP/DOWN>** buttons, select the maximum level for each color between 000-255 (000=off), and hit **<ENTER>** to confirm your choice(s).

4.) These 10 custom colors can be accessed and edited to your liking at any time, and will be saved even after powering off the fixture.

5.) Your custom static colors are directly accessible from the Effect Channel in DMX mode.

Fixture Reset Functions:

Allows users to reset the fixture to factory default settings, without loosing customized settings, or reset the custom programs exclusively.

Use the <MENU> and <UP/DOWN> buttons to navigate to LOAD and press <ENTER>, then use the <UP/DOWN> buttons to highlight ST L or PR L, and press <ENTER>.
Use the <UP/DOWN> buttons to highlight either YES or NO, then press <ENTER>.
The ST L reset function will reset all default values *with the exception of* those in ADDR (address), CTST (10 custom colors), and PROG (custom scenes and programs).
The PR L reset function will only reset all customized program settings found in the PROG settings (custom scenes and programs).

Data Sync Feature:

Users can transfer their custom settings from one fixture to another via DMX.

- 1.) Disconnect fixtures from any DMX controllers, and link them together via DMX in/out.
- 2.) On the sending fixture (DMX out), navigate the main menu using the **<UP/DOWN>** buttons

to reach **SEND**, and press the **<ENTER>** button.

- 3.) Select **YES**, and press the **<ENTER>** button to begin the transfer.
- 4.) Information for ADDR (address), or CAL (global intensity) will not be sent.
- 5.) After the data has been transferred, the receiving fixture will be automatically be reset.

Fixture Information:

These are not editable features, they are for informational purposes only.

Use the <MENU> and <UP/DOWN> buttons to navigate to INFO and press <ENTER>, then use the <UP/DOWN> buttons to highlight SOFT or POW, and press <ENTER>.
The SOFT information simply displays the current software version installed on the fixture,

and **POW** displays the fixtures current power level setting. Under normal conditions, it will be at 100%... but this fixture has built-in overheat protection that may automatically reduce the output level to 80%, or 50% in high temperature situations.

DMX Value In-Depth Reference Guide

Red Intensity 000 <> 255 (0) Green Intensity 000 <> 255 (0) Blue Intensity 000 <> 255 (0) Amber Intensity 000 <> 255 (0) White Intensity 000 <> 255 (0) White Intensity 000 <> 255 (0) UV Intensity 000 <> 255 (0) Strobe 000 <> 005 No 006 <> 020 No 006 101 <> 100 Elf 101 <> 100 111 <> 180 00 181 <> 220 221 <> 255 Elf Effect 000 <> 010 011 <> 015 Cu 011 <> 025 Cu 021 <> 020 Cu 021 <> 025 Cu 021 <> 025 Cu 026 <> 030 Cu 026 <> 030 Cu 031 <> 035 Cu 031 <> 035 Cu 041 <> 045 Cu 046 <> 050 Cu 046 <> 050 Cu	% <> 100%) % <> 100%) % <> 100%) % <> 100%) % <> 100%) % <> 100%)
Green Intensity 000 <> 255 (0) Blue Intensity 000 <> 255 (0) Amber Intensity 000 <> 255 (0) White Intensity 000 <> 255 (0) UV Intensity 000 <> 255 (0) Strobe 000 <> 255 (0) 000 <> 005 No (0) 006 <> 020 No (0) 016 <> 020 No (0) 181 <> 220 Clo (1) 181 <> 225 Clo (1) 011 <> 015 Cu (1) 011 <> 025 Cu (2) 021 <> 020 Cu (2) 021 <> 020 Cu (2) 021 <> 020 Cu (2) 021 <> 025 Cu (2) 026 <> 030 Cu (3) 031 <> 035 Cu (3) 046 <> 050 Cu (4)	% <> 100%) % <> 100%) % <> 100%) % <> 100%)
Blue Intensity 000 <> 255 (0' Amber Intensity 000 <> 255 (0' White Intensity 000 <> 255 (0' UV Intensity 000 <> 255 (0' Strobe 000 <> 200 No 006 <-> 020 No 021 <-> 060 Sy 061 <->> 000 <-> 200 No 021 <-> 060 Sy 061 <-> 020 No 021 <-> 055 St 000 <-> 220 No 021 <-> 055 Effect 000 <-> 010 Ra 141 <-> 150 Cu 011 <-> 255 Ele Effect 000 <-> 010 No 011 <-> 025 Cu 026 <-> 020 Cu 026 <-> 030 Cu 031<<<->	% <> 100%) % <> 100%) % <> 100%)
Amber Intensity 000 <> 255 (0' White Intensity 000 <> 255 (0' UV Intensity 000 <> 255 (0' Strobe 000 <> 255 (0' Strobe 000 <> 005 No 021 <> 060 Sy 061 <> 020 0101 <> 140 Ra 141 <> 180 Op 181 <> 220 Cld 221 <> 55 El Effect 000 <> 010 No 011 <> 015 Cu 011 <> 025 Cu 021 <> 025 Cu 026 <> 030 Cu 021 <> 035 Cu 031 <> 035 Cu 041 <> 045 Cu 041 <> 045 Cu 046 <> 050 Cu 046 <> 050 Cu	% <> 100%) % <> 100%)
White Intensity 000 <> 255 (0' UV Intensity 000 <> 255 (0' Strobe 000 <> 005 No 021 <> 060 Sy 061 <> 020 011 <> 100 Elic 101 <> 100 121 <> 100 Elic 101 <> 100 131 <> 220 Clic 221 <> 55 Effect 000 <> 010 No 011 <> 015 Cu 021 <> 025 Cu 021 <> 025 Cu 021 <> 035 Cu 031 <> 035 Cu 041 <> 045 Cu 041 <> 045 Cu 041 <> 050 Cu	% <> 100%)
UV Intensity 000 <> 255 (0) Strobe 000 <> 005 No 021 <> 060 Sy 061 <> 020 No 021 <> 060 Sy 061 <> 100 Ele 101 <> 140 Ra 141 <> 180 0p 181 <> 220 Cle 221 <> 055 Ele Effect 000 <> 010 No 011 <> 015 Cu 011 <> 025 Cu 026 <> 030 Cu 031 <> 035 Cu 031 <> 035 Cu 041 <> 045 Cu 041 <> 045 Cu	
Strobe 000 <> 005 006 <> 020 021 <-> 060 061 <> 020 061 <> 000 181 <> 100 181 <> 220 221 <> 255 Effect No 00 200 221 221 <> 255 Effect Effect 000 <> 010 011 <> 015 016 <> 020 021 <> 025 016 <> 030 031 <> 035 04 041 <> 040 041 <> 055 040	0/ < > 1000/)
006 <> 020 No 021 <> 060 Sy 061 <> 100 Ele 101 <> 140 Ra 141 <> 180 Op 181 <> 220 Cl 221 <> 255 Ele Effect 000 <> 010 No 011 <> 015 Cu 016 <> 020 Cu 021 <> 025 Cu 026 <> 030 Cu 031 <> 035 Cu 036 <> 040 Cu 041 <> 045 Cu 046 <> 050 Cu	% <> 100%)
011 <> 015 Cu 016 <> 020 Cu 021 <> 025 Cu 026 <> 030 Cu 031 <> 035 Cu 036 <> 040 Cu 041 <> 045 Cu 046 <> 050 Cu	o strobe on-synchronous strobe (slow <> fast) /nchronous strobe (slow <> fast) ectronic sine wave (slow <> fast) andom strobe (slow <> fast) pening pulse (slow <> fast) osing pulse (slow <> fast) ectronic square wave (slow <> fast)
$\begin{array}{c} 056 <> 060 \\ 061 <> 065 \\ 4\\ 066 <> 070 \\ 4\\ 071 <> 075 \\ 4\\ 076 <> 080 \\ 4\\ 081 <> 085 \\ 4\\ 086 <> 090 \\ 4\\ 096 <> 100 \\ 4\\ 096 <> 100 \\ 4\\ 096 <> 100 \\ 4\\ 096 <> 100 \\ 4\\ 101 <> 105 \\ 100 \\ 111 <> 115 \\ 8\\ 116 <> 120 \\ 6\\ 121 <> 125 \\ 8\\ 126 <> 130 \\ 4\\ 131 <> 135 \\ 4\\ 136 <> 140 \\ 4\\ 141 <> 145 \\ 4\\ 151 <> 155 \\ 4\\ 166 <> 150 \\ 161 <> 155 \\ 4\\ 166 <> 170 \\ 6\\ 166 <> 170 \\ 6\\ 166 <> 170 \\ 6\\ 166 <> 170 \\ 6\\ 166 <> 170 \\ 6\\ 166 <> 170 \\ 6\\ 166 <> 170 \\ 6\\ 166 <> 170 \\ 6\\ 166 <> 170 \\ 6\\ 166 <> 170 \\ 6\\ 166 <> 170 \\ 6\\ 166 <> 170 \\ 6\\ 166 <> 170 \\ 6\\ 166 <> 170 \\ 6\\ 100 \\ 10$	reen ue mber hite V

DMX Value In-Depth Reference Guide (continued)

Function	Value	What It Does
Speed (Auto 1-5)	000 <> 255	(fast <> slow)
Virtual Color Wheel	171 172 <> 210 211	Yellow Yellow (- green) Red Red (+ blue) Magenta Magenta (- red)
Dimming Mode	011 <> 020 021 <> 030 031 <> 040 041 <> 050	Square law curve Inverse square law curve S-curve Linear curve (smooth) Square law curve (smooth) Inverse square law curve (smooth) S-curve (smooth)

DMX In-Depth Reference: 12/9-Channel Modes

12-Channel	Name	9-Channel	Name
1	Dimmer (0%<> 100%)	1	Dimmer (0%<> 100%)
2	Red Intensity (0%<> 100%)	2	Red Intensity (0%<> 100%)
3	Green Intensity (0%<> 100%)	3	Green Intensity (0%<> 100%)
4	Blue Intensity (0%<> 100%)	4	Blue Intensity (0%<> 100%)
5	Amber Intensity (0%<> 100%)	5	Amber Intensity (0%<> 100%)
6	White Intensity (0%<> 100%)	6	White Intensity (0%<> 100%)
7	UV Intensity (0%<> 100%)	7	UV Intensity (0%<> 100%)
8	Strobe	8	Strobe
9	Effect	9	32-Bit Dimming
10	Auto Speed (fast <> slow)		
11	Virtual Color Wheel		
12	32-Bit Dimming		

DMX In-Depth Reference: 7/6-Channel Modes

7-Channel	Name	6-Channel	Name
1	Dimmer (0%<> 100%)	1	Red Intensity (0%<> 100%)
2	Red Intensity (0%<> 100%)	2	Green Intensity (0%<> 100%)
3	Green Intensity (0%<> 100%)	3	Blue Intensity (0%<> 100%)
4	Blue Intensity (0%<> 100%)	4	Amber Intensity (0%<> 100%)
5	Amber Intensity (0%<> 100%)	5	White Intensity (0%<> 100%)
6	White Intensity (0%<> 100%)	6	UV Intensity (0%<> 100%)
7	UV Intensity (0%<> 100%)		

DMX In-Depth Reference: 5/4-Channel Modes

5-Channel	Name	4-Channel	Name
1	Dimmer (0%<> 100%)	1	Red Intensity (0%<> 100%)
2	Amber Intensity (0%<> 100%)	2	Green Intensity (0%<> 100%)
3	White Intensity (0%<> 100%)	3	Blue Intensity (0%<> 100%)
4	UV Intensity (0%<> 100%)	4	White Intensity (0%<> 100%)
5	Virtual Color Wheel		

5. APPENDIX

A Quick Lesson On DMX

DMX (aka DMX-512) was created in 1986 by the United States Institute for Theatre Technology (USITT) as a standardized method for connecting lighting consoles to lighting dimmer modules. It was revised in 1990 and again in 2000 to allow more flexibility. The Entertainment Services and Technology Association (ESTA) has since assumed control over the DMX512 standard. It has also been approved and recognized for ANSI standard classification.

DMX covers (and is an abbreviation for) Digital MultipleXed signals. It is the most common communications standard used by lighting and related stage equipment.

DMX provides up to 512 control "channels" per data link. Each of these channels was originally intended to control lamp dimmer levels. You can think of it as 512 faders on a lighting console, connected to 512 light bulbs. Each slider's position is sent over the data link as an 8-bit number having a value between 0 and 255. The value 0 corresponds to the light bulb being completely off while 255 corresponds to the light bulb being fully on.

DMX data is transmitted at 250,000 bits per second using the RS-485 transmission standard over two wires. As with microphone cables, a grounded cable shield is used to prevent interference with other signals.

There are five pins on a DMX connector: a wire for ground (cable shield), two wires for "Primary" communication which goes from a DMX source to a DMX receiver, and two wires for a "Secondary" communication which goes from a DMX receiver back to a DMX source. Generally, the "Secondary" channel is not used so data flows only from sources to receivers. Hence, most of us are most familiar with DMX-512 as being employer over typical 3-pin "mic cables," although this does not conform to the defined standard.

DMX is connected using a daisy-chain configuration where the source connects to the input of the first device, the output of the first device connects to the input of the next device, and so on. The standard allows for up to 32 devices on a single DMX link.

Symptom	Solution
Fixture Auto-Shut Off	Check the fan in the fixture. If it is stopped or moving slower than normal, the unit may have shut itself off due to high heat. This is to protect the fixture from overheating. Clear the fan of obstructions, or return the unit for service.
No Light Output	Check to ensure fixture is operating under correct mode, IE auto/ DMX/Etc., if applicable.
Chase Speed Too Fast/Slow	Check to ensure proper setup of speed adjustment.
No Power	Check fuse, AC cord and circuit for malfunction.
Blown Fuse	Check AC cord and circuit for damage, verify that moving parts are not restricted and that unit's ventilation is not obstructed
Fixture Not Responding / Responding Er- ratically	Make sure all connectors are seated properly and securely. Use Only DMX Cables and/or check cables for defects Install a Terminator. Reset fixture(s).

Troubleshooting

Keeping Your Tournado[™] EXA As Good As New

The fixture you've received is a rugged, tough piece of pro lighting equipment, and as long as you take care of it, it will take care of you. That said, like anything, you'll need to take care of it if you want it to operate as designed. You should absolutely keep the fixture clean, especially if you are using it in an environment with a lot of dust, fog, haze, wild animals, wild teenagers or spilled drinks.

Cleaning the optics routinely with a suitable glass cleaner will greatly improve the quality of light output. Keeping the fans free of dust and debris will keep the fixture running cool and prevent damage from overheating.

In transit, keep the fixtures in cases. You wouldn't throw a prized guitar, drumset, or other piece of expensive gear into a gear trailer without a case, and similarly, you shouldn't even think about doing it with your shiny new light fixtures.

Common sense and taking care of your fixtures will be the single biggest thing you can do to keep them running at peak performance and let you worry about designing a great light show, putting on a great concert, or maximizing your client's satisfaction and "wow factor." That's what it's all about, after all!

Returns (Gasp!)

We've taken a lot of precautions to make sure you never even have to worry about sending a defective unit back, or sending a unit in for service. But, like any complex piece of equipment designed and built by humans, once in a while, something doesn't go as planned. If you find yourself with a fixture that isn't behaving like a good little fixture should, you'll need to obtain a Return Authorization (RA).

Don't worry, this is easy. Just open a support ticket at www.blizzardlighting. com/support, and we'll issue you an RA. Then, you'll need to send the unit to us using a trackable, pre-paid freight method. We suggest using USPS Priority or UPS. Make sure you carefully pack the fixture for transit, and whenever possible, use the original box & packing for shipping.

When returning your fixture for service, be sure to include the following:

- 1.) Your contact information (Name, Address, Phone Number, Email address).
- 2.) The RA# issued to you
 - 3.) A brief description of the problem/symptoms.


We will, at our discretion, repair or replace the fixture. Please remember that any shipping damage which occurs in transit to us is the customer's responsibility, so pack it well!

Shipping Issues

Damage incurred in shipping is the responsibility of the shipper, and must be reported to the carrier immediately upon receipt of the items. Claims must be made within seven (7) days of receipt.

Weight & Dimensio	ns							
Width	10.7 inches (27 cm)							
Depth	5.7 inches (14.4 cm)							
Height	8.6 inches (21.8 cm), 11.2 inches (28.4 cm) including bracket height							
Weight	11.5 lbs (5.2 kg)							
Power								
Operating Voltage	AC 100V-264V/47-63HZ							
Power Consumption	100W, 1.35A, PF: .6							
Light Source								
LED	12x 15W 6-in-1 LEDs 100,000 hours.							
Optical								
Beam Angle	25 degree							
Luminous Intensity	Lux/m	Red	Green	Blue	Amber	White	UV	ALL
	1m 2m	2,566 722	3,054 914	2,950 885	1,687 500	4,730 1,276	825 250	13,700 3,900
Thermal						_,		
Max. Operating Temp.	104 degrees F (40 degrees C) ambient							
Control								
Protocol	USITT DMX-512							
DMX Channels	4/5/6/7/9 or 12-channel DMX modes							
Input	3-pin XLR Male							
Output	3-pin XLR Female							
Other Operating Modes	Standalone, Master/Slave, Color Preset							
Other Information								
An octopus has 8 cro	tches.							
Warranty	2-year limited warranty, does not cover malfunc- tion caused by damage to LED's.							

Dimensional Drawings



This page intentionally left blank.

This page intentionally left blank.



Enjoy your product! Our sincerest thanks for your purchase! --The team @ Blizzard Lighting